

playmobil®

9315



# WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.



"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
Belangrijke documenten, bewaar deze zorgvuldig!









1









2









3









4







5







6





7







8







9






10












1



2







1



2




3








3



4








30 23 5172



30 00 2504




30 14 0932



30 08 1532




30 46 4322



30 45 0782






30 08 1412




4x 30 21 1490




30 02 8750




30 21 1480




30 22 3640



30 22 5300




30 22 5350




2x 30 21 6190





4x 30 08 1542



2x 30 28 6200




2x 30 08 1562




4x 30 22 4143




2x 30 08 1552




30 22 4112




30 08 1432



2x 30 08 1452




2x 30 08 1462



4x 30 08 1512



4x 30 08 1502



4x 30 08 1472




30 66 8180



4x 30 05 2180





2x 30 23 7352



30 07 0520



30 08 1402



2x 30 21 1500



3x 30 08 1422



30 25 9003



30 27 8280



30 25 0973



4x 30 23 8790




30 66 4790




30 25 3892



3x 30 24 5450



30 08 1482




30 08 1492



30 51 9430



30 60 1142



30 61 0602





30 09 6270



30 23 6160



30 22 2812



30 22 9713



30 04 5880



8x 30 08 1522



2x 30 24 1750



30 22 2740




4x 30 08 1442



16x 30 07 7040



48x 30 03 6600




64x 30 09 6900




4x 30 28 9280



1




2



1



2



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl



100%